



User Manual

Contents

Chapter 1 Installing and Uninstalling the Softw	are 3
1.1 Installing the Software	
1.2 Uninstalling the Software	
Chapter 2 Adding a Device	
2.1 Adding Cloud P2P Device	
2.2 Adding Local Device	
Chapter 3 Live View	6
Chapter 4 Remote Playback	
Chapter 5 Favorites Configuration	
Chapter 6 Additional Support	

Chapter 1 Installing and Uninstalling the Software

1.1 Installing the Software

Steps:

- 1. Log onto the App Store or Play Store.
- 2. Enter "Guarding Vision" to search the mobile client software.
- 3. Download and install it to your Phone.
- 4. After having installed the software successfully, you can click **(2)** to start the software.



1.2 Uninstalling the Software

Click and hold the 2 in the program list until it changes to 2. Click 2 to uninstall the mobile client software.

Chapter 2 Adding a Device

After having installed the software successfully, click 🔟 to run the software.

2.1 Adding a Cloud P2P Device

1. Click Login, Register & then Register By Email address. Enter the Security Code & create a password.

		Security Code Get Again(29)		
	+1 V Mobile Phone Number			
	Password	Enter Secu	rity code you	recive by
Login to find more.	Click Register Eorgot Password	email, ther	n click Register	r. 0
Login	Login			
You can also Add Local Device.	Enter Mobile Phone Number	4 6H1 7	5 JKL	мио
Add	Canada (+1) >	PQRS		9 wx yz
	Mobile Phone Number	<	Register	
	The phone number will be used for login or retrieving password.	Choose a j Enter pas	password sword.	
				© ~
	Register By Email Address	8 to 16 character character types: letters, and spec	rs with at least three of th numbers, lower-case let ial characters.	e following ers, upper-case
Guarding Vision Notification More	Register by Email Address		Finish	
Click + to add a	new device.			

Adding Type: Guarding Vision Domain.

Serial #: Input the Serial # Provided (Should be 9 Digits)

2.2 Adding a Local Device

1. Click add, then enter information provided.

1	al 🕈 🗈	3:35 ∢		al 🕈 💽	3:56 🕇	
≣ Q	÷	<	Add Device		<	Device Information
		Adding Type	IP/Domain Should Be	IP/Domain >	Adding Type	IP/Domain
		Alias	New Device 01 Site Ali	as * 🛛 😒	Alias	Test account
		Address	Site Address		Address	securcom.eyesonicddns
		Port	8000 Port Number (u	sually 9000)	Port	9000
Login to find more		User Name	Username		User Name	admin
Login to find more.		Password	Password		Password	
Login		Camera No.	1		Camera No.	16
Add	о.	or it may be *** either si User Nam be provide Click the	a in paddress ******** te name or ip address. he and password sho ed save icon in the top	uld right		
					Click	Start Live View.
Vision Notification	More					Start Live View

- 2. After all information is entered, click the save icon in the top right of the window.
- 3. Click Start Live View.

Chapter 3 Live View

After the device is successfully added, you can view live video from the devices, manage the alarm output of the device and control PTZ movement as well.

Note: The alarm output and PTZ control should be supported by the added device.



Chapter 4 Remote Playback

You can search the recorded video files stored in the added device for playback.

Start Playback

Steps:

- 1. Click 🖸 to enter the Remote Playback interface.
- 2. Set the start time and end time in the From and To field to define the search condition.
- 3. Select a device node and click to list all the cameras under it.
- 4. Select a camera for playback.
 - Note:

Only the camera with record during that period can be played back successfully.

5. Click Start Playback.



Chapter 5 Favorites Configuration

You can add the commonly used camera(s) to the favorites so that you can access the camera(s) conveniently.

Steps:

- 1. Click the Guarding Vision icon in the bottom left.
- 2. Click 🕂 in the top right.
- 3. Select Add to Favorites.
- 4. Select Cameras you wish to add, and click ok.

The successfully added favorites will be shown in the device list area.



Viewing the saved custom view Steps:

- 1. Click Guarding Vision in the bottom left to display the added camera list.
- 2. Saved Views will show up at the top.
- 3. Select the saved view you wish to view by clicking on the preview.
- 4. Click Start Live VIew at the bottom of the screen.

Chapter 6 Additonal Support

You can find additonal help built into the app, to find help on any others questions you may have follow these steps.

Steps:

- 1. Click the more icon in the bottom right.
- 2. Select Help.
- 3. Search for a Topic or scroll down for frequenlty asked questions.

1:15 🔊		l 🗢 🗈		
	More			
Pictur	es and Videos	>		
🛞 Mana	ge Sharing Settings	>		
Accou	unt Management			
Settin	gs	>		
C Reset	Device Password	>		
Confi	gure Network	>		
Performance Performance		>		
Ø Feedl	pack	>		
(i) About	t	>		
	Logout			
	2. Select Hel	р.		
1. Select More.				
		N		
Guarding Vis	ion Notification	More		

1:15 🛷		al 🗢 🗈	
<	Help		
Guardi Client	ng Vision iOS M	obile	
Search			
	Legal Information	on	
ł	Symbol Conventi	ons	
	Introduction		
The designe With the devices	Guarding Vision mobile clie d for the phone based on iC e Mobile Client, you can rem s (NVRS 1998 1990) can	nt (iOS), is IS 8.0 or later. notely control Deras, indoor	
000000	, meno, peno, network can		

